

# WHEEL HANDLER

Wheel Handler P/n 110.0200

## **REMOVE AND REFIT**

 Wheel assemblies and \*Hubs

# POSITION

 Wheel assemblies and \*Hubs at any angle for servicing



#### SAFE

- No heavy lifting.
- The Wheel Handler holds the wheel assembly in a comfortable working position while maintenance is carried out.

# FAST

- Increase workshop profits.
- Reduce labour costs.
- Reduce vehicle down time.

# FEATURES

\*Optional hub kit required.

## PRECISE

- Excellent visibility.
- Infinite fore and aft wheel tilt.
- Large caster wheels for easy manoeuvring.
- Simple height control.






















# **SLEECO**

### **OPTIONAL TOOLS**

#### HUB KIT P/n 110.0201

• The hub kit allows the drum brake hub or disc brake hub to be quickly and easily removed, serviced and refitted accurately with no heavy lifting.





#### BRAKE DRUM BOLT HOLDER P/n 110.0202

• The bolt holder allows one person to quickly and easily remove and replace brake drum nuts and bolts on spider or spoke hubs.

#### **SPECIFICATIONS**

- MODEL HEAVY ROAD TRANSPORT AND BUS
- This model wheel handler is designed for 11R22.5 wheels and will perform best with most wheels with 20" to 22.5" rims.
- NOTE: some vehicles have very restricted wheel access in their body panels, the use of this wheel handler in these vehicles may be restricted.



- Lifting capacity: certified at 300kilograms WLL
- Width 1100mm (set for the smallest wheel diameter)
- Depth: 900mm
- Height: 1000mm
- Weight: 110 Kilograms
- Wheels: 4 x 100mm castor wheels two with brakes