



Index No.	Part No.	Description	Qty.	Index No.	Part No.	Description	Qty.
<b>A</b>	<b>8940168843</b>	<b>Housing Kit</b>		<b>E</b>	<b>8940168850</b>	<b>Gear Kit</b>	
1		Motor Housing	1	19		Spacer	1
34		Rubber Grip	1	22		Internal Gear	2
<b>B</b>	<b>8940168844</b>	<b>Inlet Kit</b>		26		Work Spindle	1
3		Air Inlet	1	27		Reduction Spindle	1
31		Exhaust Diffuser	1	28		Ball Bearing	2
32		Screw	2	29		Washer	1
<b>C</b>	<b>8940168845</b>	<b>Trigger Kit</b>		<b>E1</b>	<b>8940168857</b>	<b>Planet gear KIT</b>	
2		Spring Pin	1	20		Pinion Gear	1
4		Trigger	1	21		Center Gear	1
5		Valve Stem	1	23		Planet Gear	6
6		Reverse Bushing	1	24		Pin	6
7		O-Ring	1	25		Needle Bearing	6
8		Valve Spring	1	<b>F</b>	<b>8940168854</b>	<b>Spindle Kit</b>	
9		O-Ring	1	35		Spindle Assembly	1
10		Reverse Lever	1	36		Set Of Screw	1
30		O-Ring	1	29		Washer	1
<b>D</b>	<b>8940168846</b>	<b>Motor Kit</b>		33	2050485413	Clamp Nut	1
11		Motor Gasket	1	<b>G</b>	<b>8940168856</b>	<b>Handle Kit</b>	
15	2050485903	Rotor	1	37		Handle (optional)	1
16	2050485913	Rotor Blades (Set Of 5)	1	38		Retainer (optional)	1
17		Spring Pin	1		6158727610	Warning label	
18	2050485933	Cylinder	1		6158727620	Warning label	
<b>D1</b>	<b>8940168847</b>	<b>End Plate Kit</b>			6158727630	Warning label	
13		Ball Bearing	2		2050507803	Tune up kit (7,9,13,16,25,28,30,11,17)	
14		End Plate	2				
					6159948700	SAFETY INSTRUCTIONS	
					8940168823	OPERATOR'S MANUAL	
					8940168670	EC DECLARATION	

Spare parts without part number are not sold separately

8940168825